



INSTALLATION OF BOLT ON COUPLING:

1. LOCATE AND CUT HOLE TO ACCEPT O.D. OF COUPLING.
2. INSERT COUPLING IN HOLE AND MARK BOLT HOLES.
3. REMOVE COUPLING AND DRILL BOLT HOLES TO ACCEPT 3/8"-16 BOLTS.
4. APPLY A BEAD OF SILICONE AROUND BODY OF COUPLING AND AROUND BOLT HOLES.
5. INSERT BOLT ON COUPLING ASSEMBLY AND TIGHTEN BOLTS EVENLY.

DIMENSIONAL DATA		
PART NO.	"A" DIMENSION	"B" DIMENSION
BOC125SS	1 1/4"	6"
BOC150SS	1 1/2"	6"
BOC200SS	2"	6"
BOC300SS	3"	8"
BOC400SS	4"	8"



STEELE PLASTICS, INC.  
P.O. Box 1076 / 1280 Sturgis Rd.  
Conway, AR 72033  
(501) 327-5122 Fax (501) 327-0807

TITLE BOLT-ON COUPLING, STAINLESS STEEL

PROJECT

CUSTOMER

JOB NO.

P.O. NO.

DWG. NO. BOCOUPPING STAINLESS