



INSTALLATION OF BOLT ON COUPLING:

1. LOCATE AND CUT HOLE TO ACCEPT O.D. OF COUPLING.
2. INSERT COUPLING IN HOLE AND MARK BOLT HOLES.
3. REMOVE COUPLING AND DRILL BOLT HOLES TO ACCEPT 3/8"-16 BOLTS.
4. APPLY A BEAD OF SILICONE AROUND BODY OF COUPLING AND AROUND BOLT HOLES.
5. INSERT BOLT ON COUPLING ASSEMBLY AND TIGHTEN BOLTS EVENLY.

DIMENSIONAL DATA		
PART NO.	"A" DIMENSION	"B" DIMENSION
BOC125	1 1/4"	6"
BOC150	1 1/2"	6"
BOC200	2"	6"
BOC300	3"	8"
BOC400	4"	8"



STEELE PLASTICS, INC.
 1280 Sturgis Rd.
 Conway, AR 72034
 (501) 327-5122 Fax (501) 327-0807

TITLE BOLT-ON COUPLING, CARBON STEEL

PROJECT

JOB NO.

P.O. NO.

CUSTOMER

DWG. NO. BOCOUPPING CARBON